

CRAWLBRELLA DOOR INSTALLATION INSTRUCTIONS

Here is a detailed, step-by-step instruction guide for installing your new Crawlbrella Door. This guide is designed to ensure that you can install the door efficiently and safely.

Before You Begin

- **Read Instructions**: Ensure you thoroughly read through these instructions before starting the installation process.
- **Gather Tools**: Make sure you have all the required tools ready. You will need a Hammer Drill, 5/16" Masonry Drill Bit, Phillips Bit or Screwdriver, and a Marker (preferably a Sharpie).

Parts Included

- (4) 1-1/2" Screws
- (4) Plastic Anchors

Removing the Door (If applicable)

1. **Unlock the Top Latch**: Turn the top latch to the right or left. This latch can be padlocked for extra security.
2. **Remove the Door**: Tilt the door forward and lift it up out of its frame.

Installing the Door

Position the Frame

1. **Remove the Door Core**: Take the door core out of the frame to make the installation easier.
2. **Position the Frame**: Place the door frame in the desired opening of your concrete block or brick wall. It's recommended to position the frame as close to the front edge of the opening as possible for a better fit and appearance.
3. **Mark Drill Points**: Using your marker, trace through the pre-drilled holes in the aluminum frame onto your wall's surface to indicate where you will need to drill.

Drill and Install Anchors

4. **Remove the Frame**: Take the frame away from the opening to start drilling.
5. **Drill Holes**: Use your hammer drill and the 5/16" masonry drill bit to drill holes where you've marked. The holes should be roughly 1-1/2" deep.
6. **Insert Plastic Anchors**: Place a plastic anchor into each drilled hole, ensuring they are flush with the wall's surface.

CRAWLBRELLA DOOR INSTALLATION INSTRUCTIONS

Secure the Frame

7. **Reposition the Frame**: Place the frame back into the opening, aligning it with the plastic anchors.
8. **Screw in the Frame**: Using the 1-1/2" screws provided, secure the frame into the wall through the pre-drilled holes and into the anchors. A Phillips bit or screwdriver will be required for this step. DO NOT overtighten and bow the sides of the framing.

Finishing Touches

9. **Fill Gaps**: If there are any gaps between the aluminum frame and the concrete block or brick, it's recommended to use mortar caulking or a similar material to fill these gaps. This will provide a better seal and finish.
10. **Reattach the Door Core**: Once the frame is securely installed and any gaps are filled, reattach the door core to the frame by reversing the removal process.

Safety and Final Checks

- **Check for Stability**: Ensure the door and frame are securely installed. The door should open smoothly and latch securely.
- **Locking Mechanism**: Test the top latch to ensure it locks and unlocks as expected. If you have a padlock, attach it to test the added security feature.

Congratulations! You've successfully installed your Crawlbrella Door. Enjoy the added security and convenience it brings to your home. If you encounter any complications during the installation process or if the door is not functioning as expected, refer back to these instructions, or contact the manufacturer for assistance.